

Pride® Lifts

Mobility Made Easy

Backpacker AVP 2.0

Backpacker® Interior Lifts are specifically engineered for scooter and power chair transportation, while providing concealment and weather protection for your mobility product. The low-profile, one-piece design allows for easy loading and unloading of your mobility product; simply drive on and off the all-steel constructed platform. Features include a durable 12-volt motor with an easy-to-use two button wired and wireless hand control for simple and reliable operation. Most applications do not require drilling or vehicle modification and include a kit for quick and easy installations.

BASE WEIGHT	193 lbs. ¹
MAXIMUM SCOOTER/PC OVERALL WEIGHT	350 lbs.
MAXIMUM PRODUCT WIDTH	27"
OVERALL PLATFORM LENGTH	42"-34" (41"-33" usable surface)
MAXIMUM TRAVEL DISTANCE FROM THE GROUND	37"
MOTOR	Sealed 12 Volt DC
WARRANTY	3-Year Transferable
VEHICLE PLATFORM	Minivan, Full-size van ¹ , SUV and Crossover
LIFTS CURRENT PRODUCTS ³	All Pride® Scooters & Pride®/Quantum® PWCs with contoured, Specialty & Synergy® seating, And equivalent competitor products Except: Pursuit®, Pursuit® XL, Raptor

1. May not include some accessories
2. May require vehicle modification
3. Vehicle dependent

To find a compatible lift for your vehicle and mobility product, use our new

LIFT FINDER

pridemobility.com/lift-finder

FEATURES AND BENEFITS

- **New** standard dual remote provides safe, easy hardwire and wireless operation
- **New** rear hatch safety sensor disables lift when rear hatch is closed
- **New** redesigned hardwire routing provides easy installation with no fears of pinching or damaging power harness during operation
- **New** puddle light for platform illumination in low-light settings
- **New** hand control Lockout feature for quick and easy prevention of unauthorized operation
- **New** low battery warning beeps and flashes when battery reaches under 10 volts



MADE IN
USA